

# adhesive double door block

## Instructions for use



Uncompromising on safety, only high performance materials are used in the manufacture of the Fred range. This Double Door Block is engineered from top quality ABS and POM.

### What's included:

- (A) 1 x Block
- (B) 1 x Top Fix Locking Tab
- Central Support Locking Tabs
- (C) 1 x Small (D) 1 x Medium
- (E) 1 x Large (F) 1 x Extra Large
- (G) Mounting Plate
- (H) EZ-Dock™



### Important!

Fred wants to keep you and your family safe but we need you to do your bit, please read and follow these instructions carefully. Once your product has been installed, please keep these instructions in a safe place for future reference.

Step by step video fitting guides at  
[www.fredsafety.co.uk](http://www.fredsafety.co.uk)

## Recommended Usage

Use on cabinets and appliances with doors 6-21mm thick. If the cabinet has a central vertical support behind the 2 doors, this should be 15mm or wider. If there is no vertical support, the underside of the cabinet needs to be a flat surface.

## Step by step installation guide

1



Fred adhesives are instantly strong. They cannot be repositioned when placed incorrectly so test each step first, **without** exposing the adhesive. Before installation, clean and dry the surface with a 50:50 solution of water plus white vinegar or surgical spirit.

2



Remove the protective layer to expose the adhesive strip on the EZ-Dock™ (H) and stick it out of your child's reach where you wish to store the Block. Push firmly into place for 30 seconds then leave for 24 hours before use.

### Option A:

### Where the cabinet has a vertical support behind the doors

3 A



Attach the Block (A) to each of the Locking Tabs (C-F) in turn, and choose the fitting combination that fits most snugly around the thickness of the door. The Locking Tabs slide in to the back of the Block and are attached/released by squeezing the two buttons on the Block together.

4 A



Slide the preferred Locking Tab into the Mounting Plate (G) and then attach the Block.

5 A



Hold the assembled unit around the thickness of one door, with the Block facing towards you. Check that in this position, the door can still close properly.

6 A



Remove the protective layer to expose the adhesive on the Locking Tab, and close the door firmly for 30 seconds. Remove the Block, so that both doors can be closed, and leave for 24 hours before first use.

3 B



Attach the Block (A) to the Top Fix Locking Tab (B). The Locking Tab slides in to the back of the Block and is attached/released by squeezing the two buttons on the Block together.

4 B



Hold the assembled Block and Locking Tab around the thickness of one of the doors, with the Block facing towards you, pushed against the front of the cupboard door, and the adhesive of the Locking Tab facing up.

5 B



Remove the protective layer to expose the adhesive on the Locking Tab. Shut the door and slide the Block up until the Locking Tab adheres to the top of the cabinet.

6 B



Remove the Block, open the door, and push the Locking Tab firmly into place for 30 seconds. Both doors can then be closed, and the Block left for 24 hours before first use.

1 To open and close



Squeeze the 2 buttons on the Block together, and pull the Block gently towards you. Once the Block has been removed, the doors can be opened and closed as usual. To reattach the Block, reverse these actions.

2



Lock the Block onto the EZ-Dock™ when not in use. The locking tab remains visible as a reminder that the doors are unlocked.

To permanently remove



Use a blunt knife to carefully prise away the Tab from the surface, and rub away any residual adhesive with your fingers.

## Safety Warnings

- **WARNING!** Adult assembly required.
- **ATTENTION!** This product acts as a deterrent but cannot replace adult supervision. Never leave children unattended. This is not a toy, do not allow children to play with it.
- Check the product regularly to ensure it is safe to use and working correctly. If worn or damaged, remove immediately and replace as needed.
- This product is designed to offer protection for children up to the age of approximately 24 months.
- If your child has learnt how to remove the product, stop using it immediately.
- Not suitable for use on high heat-generating appliances (e.g. ovens, microwaves).

## Other Important Information

- **Care instructions:** Wipe with a damp cloth. Do not immerse this product in water.
- **Caution!** Fred adhesives may cause damage to some surfaces. We accept no liability or responsibility for damage or defects arising from the use of the adhesive on any furniture or surfaces. This product is most suitable for cabinets made of solid material e.g. wood. If the surface of the cabinet is laminated, the adhesive attaching the laminate to the inner material (usually mdf or chipboard) may not be strong enough to withstand a strong tug on the Block by a child. If this is the case, you will need to use screws to install this product.
- Occasionally, you will need to use a 50:50 mix of water plus either white vinegar or surgical spirit to remove adhesive residue. This mix could cause damage to some surfaces, so please test its use on a discreet area first. We do not accept any liability for damage so caused.
- Claims against warranties or guarantees must be arranged through your retailer, seller or trader. Proof of original purchase is required.

Carefully designed, top quality products for protecting against falls, finger-traps, electric shocks, burns and access to dangerous objects are what Fred is all about.

We can help you more at [www.fredsafety.co.uk](http://www.fredsafety.co.uk)