

invisible magnet lock

Instructions for use



Uncompromising on safety, only high performance materials are used in the manufacture of the Fred range. This Invisible Magnet Lock is engineered from top quality ABS, POM and magnets.

What's included:

- (A) 2 x Catch (B) 2 x Hook (C) 1 x EZ-Tool™
- (D) 1 x Key (E) 1 x EZ-Dock™ (F) 6 x Stickers
- (G) 4 x Screw



Important!

Fred wants to keep you and your family safe but we need you to do your bit, please read and follow these instructions carefully. Once your product has been installed, please keep these instructions in a safe place for future reference.

Step by step video fitting guides at www.fredsafety.co.uk

Step by step installation guide

Suitable for installation on cupboards and deeper drawers where the upper and side surfaces of the cabinet are flat. For drawers, the side of the drawer needs to be shorter than the drawer front by at least 7cm. Use adhesive to attach Catch to the top of the cabinet, or screws for attaching to the side.

1



Fred SecureHold™ adhesive is instantly strong. It cannot be repositioned when placed incorrectly so test each step first, **without** exposing the adhesive. Before installation, clean and dry the surface with a 50:50 solution of water plus white vinegar or surgical spirit.

2



If attaching Catch to top of cabinet, peel off the protective layer to expose the adhesive on the Catch (A).

3



For cupboards, the Catch should be positioned either into the top corner, or within 20cm of the opening edge of the door. Hold the Catch diagonally against the top of the cabinet. The thin arm should be flush with the outside of the cabinet.

4



Slide the Catch up, and hold firmly in position for 30 seconds.

Alternative: If attaching to side of cabinet, use the Screws (G) to position the Catch in place. Ensure the thin arm is flush with the edge of the cabinet.

5



Slide the EZ-Tool™ (C) into the Hook (B).

6



Then slide the EZ-Tool™ into the Catch.

7



Remove the protective layer from the back of the Hook to expose the adhesive.

8



Keeping all 3 components together, gently close the drawer or cupboard door, and hold closed for 30 seconds. Place a Sticker (F) on the cupboard door to indicate the position of the lock.

9



Holding the Key (D) against the sticker, gently open the cupboard or drawer, and remove the EZ-Tool™. Leave for 24 hours to ensure maximum adhesion.

10



Remove the protective layer to expose the adhesive on the EZ-Dock™ and stick it out of your child's reach, where you wish to store the Magnetic Key. Push firmly into place for 30 seconds, then leave for 24 hours before use. Keep the Key on the EZ-Dock™ so you always know where it is.

To open and close



To use, pull the Key from the EZ-Dock™ and hold it against the Sticker while simultaneously gently opening the cupboard or drawer. Replace the Key on the EZ-Dock™. Simply remove the Sticker when it is no longer required.

To permanently remove



Use a blunt knife to gently prise the Hook, Catch and EZ-Dock™ off of the units, and rub away any residual adhesive with your fingers.

Safety Warnings

- **WARNING!** Adult assembly required.
- **ATTENTION!** This product acts as a deterrent but cannot replace adult supervision. Never leave children unattended. This is not a toy, do not allow children to play with it.
- Check the product regularly to ensure it is safe to use and working correctly. If worn or damaged, remove immediately and replace as needed.
- This product is designed to offer protection for children up to the age of approximately 24 months.
- If your child has learnt how to remove the product, stop using it immediately.
- Not suitable for use on high heat-generating appliances (e.g. ovens, microwaves).
- Keep all magnets out of reach of children at all times.

Other Important Information

- **Care instructions:** Wipe with a damp cloth. Do not immerse this product in water.
- **Caution!** Fred SecureHold™ adhesive may cause damage to some surfaces. We accept no liability or responsibility for damage or defects arising from the use of the adhesive on any furniture or surfaces.
- Occasionally, you will need to use a 50:50 mix of water plus either white vinegar or surgical spirit to remove adhesive residue. This mix could cause damage to some surfaces, so please test its use on a discreet area first. We do not accept any liability for damage so caused.
- Claims against warranties or guarantees must be arranged through your retailer, seller or trader. Proof of original purchase is required.

Carefully designed, top quality products for protecting against falls, finger-traps, electric shocks, burns and access to dangerous objects are what Fred is all about.

We can help you more at www.fredsafety.co.uk