

# adhesive top drawer catch

## Instructions for use

**Fred**<sup>®</sup>  
safety just got smarter

Uncompromising on safety, only high performance materials are used in the manufacture of the Fred range. This Top Drawer Catch is engineered from top quality POM.



### Important!

Fred wants to keep you and your family safe but we need you to do your bit, please read and follow these instructions carefully. Once your product has been installed, please keep these instructions in a safe place for future reference.

Step by step video fitting guides at [www.fredsafety.co.uk](http://www.fredsafety.co.uk)

## Recommended Usage

Use on top drawers or cupboards where the inside of the cabinet above the drawer is flat. Worktops can overhang the drawer unit by up to 20mm. If using a drawer insert to tidy cutlery etc. you will need a minimum of 40mm space between the top of the insert and the top of the drawer.

## Step by step installation guide

1



Fred SecureHold™ adhesive is instantly strong. It cannot be repositioned when placed incorrectly so test each step first, **without** exposing the adhesive. Before installation, clean and dry the surface with a 50:50 solution of water plus white vinegar or surgical spirit.

2



Slide the EZ-Tool™ (A) onto the Catch (B). The broad plate at the end of the EZ-Tool™ fits into the recess on the adhesive side of the Catch.

3



Place the EZ-Tool™ and Catch onto the Arm (C) so that the locator pin fits into the hole on the top of the Arm.

4



Remove the protective layer to expose the adhesive strip on the Catch.

5



Open the drawer and hold the stop tab of the EZ-Tool™ diagonally against the overhang of the worktop.

6



Roll the entire assembly up until the Catch adheres to the cabinet, keeping the stop tab in contact with the worktop at all times. Push the Catch firmly onto the cabinet and hold for 30 seconds.

7



Keeping all 3 parts together, swivel the EZ-Tool™/hook slightly until the back plate is parallel to the drawer/door as they come into contact. Remove the protective layer to expose the adhesive strip on the back plate.

8



Gently close the drawer until it comes into contact with the back plate, and use your fingers to press it firmly in to place for 30 seconds.

9



With your fingers still holding the back plate, use your other hand to push the Arm down.

10



Open the drawer and lift off the EZ-Tool™. Leave for 24 hours before first use.

### To open and close



Open the drawer until it stops, use your fingers to push down onto the Arm to release the drawer. Closing slowly, the Catch will automatically reengage as you shut the drawer. It will not completely close until you push the Arm down again.

### To temporarily remove



Pull the removal tab up at the same time and slide the hook horizontally out of the back plate. To reassemble, slide the hook back in until it clicks into position.

### To permanently remove



Use a blunt knife to carefully prise the Catch and the back plate from the surface, and rub away any residual adhesive with your fingers.

## Safety Warnings

- **WARNING!** Adult assembly required.
- **ATTENTION!** This product acts as a deterrent but cannot replace adult supervision. Never leave children unattended. This is not a toy, do not allow children to play with it.
- Check the product regularly to ensure it is safe to use and working correctly. If worn or damaged, remove immediately and replace as needed.
- This product is designed to offer protection for children up to the age of approximately 24 months.
- If your child has learnt how to remove the product, stop using it immediately.
- Not suitable for drawers or cabinets next to, above or below high heat-generating appliances (e.g. hobs).

## Other Important Information

- **Care instructions:** Wipe with a damp cloth. Do not immerse this product in water.
- **Caution!** Fred SecureHold™ adhesive may cause damage to some surfaces. We accept no liability or responsibility for damage or defects arising from the use of the adhesive on any furniture or surfaces.
- Occasionally, you will need to use a 50:50 mix of water plus either white vinegar or surgical spirit to remove adhesive residue. This mix could cause damage to some surfaces, so please test its use on a discreet area first. We do not accept any liability for damage so caused.
- Claims against warranties or guarantees must be arranged through your retailer, seller or trader. Proof of original purchase is required.

## Making homes safer with Fred...



Lower Drawer Catch



Corner Protector



Invisible Cupboard Lock

Carefully designed, top quality products for protecting against falls, finger-traps, electric shocks, burns and access to dangerous objects are what Fred is all about.

We can help you more at [www.fredsafety.co.uk](http://www.fredsafety.co.uk)